



**SALE**

|                                       |       |  |   |
|---------------------------------------|-------|--|---|
| IDLE PROMPT                           |       |  | Swipe card.   |
| Press here for...                     |       |  |   |
| SALE                                  | X     |  | Swipe card or key in card number.   |
| Swipe/Enter Card                      |       |  |   |
| <-- Clear                             | Enter |  |   |
| CARD TYPE SALE                        | X     |  | Key in expiration date in MMYY format (example: 1202) and touch or press [ENTER]. |
| Expiration Date MMYY                  |       |  |   |
| <-- Clear                             | Enter |  |   |
| CARD TYPE SALE                        | X     |  | Key in last 4 digits of customer's card and touch or press [ENTER].               |
| Enter last 4 numbers of customer card |       |  |   |
| <-- Clear                             | Enter |  |   |
| CARD TYPE SALE                        | X     |  | Key in cashier number and touch or press [ENTER].                                 |
| Enter Cashier Number                  |       |  |   |
| <-- Clear                             | Enter |  |   |
| CARD TYPE SALE                        | X     |  | Key in amount and touch or press [ENTER].   |
| Amount                                |       |  |   |
| \$\$                                  |       |  |   |
| <-- Clear                             | Enter |  |   |
| CARD TYPE SALE                        | X     |  | Touch Yes or press [ENTER] if amount is correct.                                  |
| Total Correct? \$\$                   |       |  | Touch No and change amount if not correct.  |
| NO YES                                |       |  |   |
| <-- Clear                             | Enter |  |   |
| CARD TYPE SALE                        | X     |  | Key in invoice number and touch or press [ENTER].                                 |
| Enter Invoice #                       |       |  |   |
| <-- Clear                             | Enter |  |   |
| RESPONSE                              |       |  | Approval code displays. Receipt prints. Terminal returns to idle prompt.          |
| APPROVAL XXXXXX                       |       |  |   |
| CARD TYPE SALE                        | X     |  | Key in PO number and touch or press [ENTER], or press [ENTER] to bypass.          |
| P. O. / I. D. Number                  |       |  |   |
| <-- Clear                             | Enter |  |   |
| TAX I.D.                              |       |  | Key in the appropriate code and touch or press [ENTER].                           |
| 0=None 1=Present 2=Exempt             |       |  |   |
| Enter Tax Amount                      |       |  | Key in the tax amount and touch or press [ENTER].                                 |
| Tax Amount: \$\$                      |       |  |   |

**MANUALLY-ENTERED SALE**

|  |   |       |   |
|--|---|-------|---|
| <b>IDLE PROMPT</b><br>Press here for . . . |   |       | Press [MENU], [NEW TRANS], and then [SALE].   |
| Swipe/Enter Card                           | SALE  | X     | Key in card number and touch or press [ENTER].  |
| <--  | Clear   | Enter |   |
| CARD TYPE                                  | SALE  | X     | Key in expiration date in MMY format (example: 1202) and touch or press [ENTER].            |
| <--  | Expiration Date                                   | Enter |   |
| CARD TYPE                                  | SALE  | X     | Server manually imprints card and presses [OK] to continue.                                 |
| <--  | Take Imprint of Card                              | Enter |   |
| CARD TYPE                                  | SALE  | X     | Key in cashier number and touch or press [ENTER].   |
| <--  | Enter Cashier Number                              | Enter |   |
| CARD TYPE                                  | SALE  | X     | Key in CVV2 code from back of card and press [ENTER].                                       |
| <--  | CVV2 from Card                                    | Enter |   |
| CARD TYPE                                  | SALE  | X     | Select appropriate CVV2 code. [ENTER].  |
| <--  | CVV2: 0=Unknown<br>2=CANNOT READ<br>9=NOT ON CARD | Enter |   |
| CARD TYPE                                  | SALE  | X     | Key in amount and touch or press [ENTER].   |
| <--  | Amount  | Enter |   |
|  | \$\$  |       |   |
| CARD TYPE                                  | SALE  | X     | Touch Yes or press [ENTER] if amount is correct. Touch No and change amount if not correct. |
| <--  | Total Correct? \$\$                               | Enter |   |
|  | NO  | YES   |   |
| CARD TYPE                                  | SALE  | X     | Key in invoice number and touch or press [ENTER].   |
| <--  | Enter Invoice #                                   | Enter |   |
|  | RESPONSE  |       | Approval code displays. Receipt prints. Terminal returns to idle prompt.                    |
|  | APPROVAL XXXXXX                                   |       |   |

**SETTLEMENT**

|  |                      |       |  |
|--|----------------------|-------|--|
| <b>IDLE PROMPT</b><br>Press here for . . . |                      |       | Press [MENU], [BATCH], and then [SETTLE].                                |
| Enter Password                             | SETTLE               | X     | Key in password and press [ENTER].                                       |
| <--  | Clear                | Enter |  |
|  | SETTLE IN PROGRESS   |       | No action while processing.  |
| Enter Sales Total s                        | SETTLE               | X     | Merchant keys in sales totals from report.                               |
| <--  | Clear                | Enter |  |
| Enter Refund Total s                       | SETTLE               | X     | Merchant keys in return totals from report.                              |
| <--  | Clear                | Enter |  |
|  | BATCH TRANSFER, WAIT |       | No action while processing.  |
|  | RESPONSE             |       | Approval code displays. Receipt prints. Terminal returns to idle prompt. |
|  | OK XXX XXX XXXX      |       |  |

**AUTHORIZATION ONLY**

|  |                                       |       |   |
|--|---------------------------------------|-------|---|
| <b>IDLE PROMPT</b><br>Press here for . . . |                                       |       | Press [MENU], [NEW TRANS], and then [AUTH ONLY].  |
| Swipe/Enter Card                           | AUTH ONLY                             | X     | Swipe card or key in card number and touch or press [ENTER].                                |
| <--  | Clear                                 | Enter |   |
| CARD TYPE                                  | AUTH ONLY                             | X     | Key in last 4 digits of customer's card and touch or press [ENTER].                         |
| <--  | Enter last 4 numbers of customer card | Enter |   |
| CARD TYPE                                  | AUTH ONLY                             | X     | Key in cashier number and touch or press [ENTER].   |
| <--  | Enter Cashier Number                  | Enter |   |
| CARD TYPE                                  | AUTH ONLY                             | X     | Key in amount and touch or press [ENTER].   |
| <--  | Amount                                | Enter |   |
|  | \$\$                                  |       |   |
| CARD TYPE                                  | AUTH ONLY                             | X     | Touch Yes or press [ENTER] if amount is correct. Touch No and change amount if not correct. |
| <--  | Total Correct? \$\$                   | Enter |   |
|  | NO                                    | YES   |   |
| CARD TYPE                                  | AUTH ONLY                             | X     | Key in invoice number and touch or press [ENTER].   |
| <--  | Enter Invoice Number                  | Enter |   |
|  | RESPONSE                              |       | Approval code displays. Receipt prints. Terminal returns to idle prompt.                    |
|  | APPROVAL XXXXXX                       |       |   |

**FORCED SALE**

|  |                                       |       |   |
|--|---------------------------------------|-------|---|
| <b>IDLE PROMPT</b><br>Press here for . . . |                                       |       | Press [MENU], [NEW TRANS], and then [FORCE].  |
| Swipe customer card                        | FORCE                                 | X     | Swipe card or key in card number.   |
| CARD TYPE                                  | FORCE                                 | X     | Key in last 4 digits of customer's card and touch or press [ENTER].                         |
| <--  | Enter last 4 numbers of customer card | Enter |   |
| CARD TYPE                                  | FORCE                                 | X     | Key in cashier number and touch or press [ENTER].   |
| <--  | Enter Cashier Number                  | Enter |   |
| CARD TYPE                                  | FORCE                                 | X     | Key in amount and touch or press [ENTER].   |
| <--  | Amount                                | Enter |   |
|  | \$\$                                  |       |   |
| CARD TYPE                                  | FORCE                                 | X     | Touch Yes or press [ENTER] if amount is correct. Touch No and change amount if not correct. |
| <--  | Total Correct? \$\$                   | Enter |   |
|  | NO                                    | YES   |   |
| CARD TYPE                                  | FORCE                                 | X     | Key in invoice number and touch or press [ENTER].   |
| <--  | Enter Invoice Number                  | Enter |   |
| CARD TYPE                                  | FORCE                                 | X     | Key in approval code and touch or press [ENTER].  |
| <--  | Enter Approval Code                   | Enter |   |
|  | RESPONSE                              |       | Approval code displays. Receipt prints. Terminal returns to idle prompt.                    |
|  | TRANSACTION ACCEPTED                  |       |   |

| REFUND  |                      |  |   |
|---|----------------------|--|---|
| IDLE PROMPT<br>Press here for...                                      |                      | Press [MENU], [NEW TRANS], and then [REFUND].                            |   |
| CREDIT CARD<br>EBT  | REFUND<br>DEBIT CARD | X  | Press [CREDIT] for credit card; press [DEBIT] for debit card.       |
| Swipe Customer Card   |                      | X  | Swipe card or key in card number.                                   |
| CARD TYPE<br>Enter last 4 numbers<br>of customer card<br><--<br>Clear | REFUND               | X  | Key in last 4 digits of customer's card and touch or press [ENTER]. |
| CARD TYPE<br>Enter Cashier<br>Number<br><--<br>Clear                  | REFUND               | X  | Key in cashier number and touch or press [ENTER].                   |
| CARD TYPE<br>Amount<br><--<br>Clear                                   | REFUND               | X  | Key in amount and touch or press [ENTER].                           |
| CARD TYPE<br>Enter Invoice<br>#<br><--<br>Clear                       | REFUND               | X  | Key in invoice number and touch or press [ENTER].                   |
| RESPONSE<br>TRANSACTION ACCEPTED                                      |                      | Approval code displays. Receipt prints. Terminal returns to idle prompt. |   |

| VOID   |                       |  |  |
|--|-----------------------|--|--|
| IDLE PROMPT<br>Press here for...                     |                       | Press [MENU], [BATCH], and then [VOID].                                  |  |
| Enter Station ID<br>XX (displays current station ID) |                       | X  | Key in the Station ID of the terminal that originally ran the transaction that is to be voided and press [ENTER]. (The Station ID can be located on the original receipt.) |
| Enter Invoice<br>Number<br><--<br>Clear              |                       | X  | Key in invoice number and touch or press [ENTER].  |
| XXXXXX<br>Correct?<br>NO                             | VOID<br>\$X.XX<br>YES | X  | Touch [YES] to void the transaction, or touch [NO] to select another transaction.  |
| RESPONSE<br>TRANSACTION ACCEPTED                     |                       | Approval code displays. Receipt prints. Terminal returns to idle prompt. |  |

| ADJUST   |  |  |  |
|--|--|--|--|
| IDLE PROMPT<br>Press here for...                     |  | Press [MENU], [BATCH], and then [ADJUST].                                |  |
| Enter Cashier<br>Number<br><--<br>Clear              |  | ADJUST<br>X  | Key in cashier number and press [ENTER].   |
| Enter Station ID<br>XX (displays current station ID) |  | ADJUST<br>X  | Key in the Station ID of the terminal that originally ran the transaction that is to be adjusted and press [ENTER]. (The Station ID can be located on the original receipt.) |
| Enter Invoice<br>Number<br><--<br>Clear              |  | ADJUST<br>X  | Key in invoice number and touch or press [ENTER].  |
| Base Amount<br>Enter Tip<br><--<br>Clear             |  | ADJUST<br>\$XXXX.XX<br>X   | Key in tip amount, or press [ENTER] to adjust amount.  |
| Total Correct?<br>NO                                 |  | ADJUST<br>\$\$<br>YES  | Touch Yes or press [ENTER].  |
| Enter Amount<br><--<br>Clear                         |  | ADJUST<br>X  | Key in new amount and touch or press [ENTER].  |
| Enter Tip<br><--<br>Clear                            |  | ADJUST<br>X  | Key in new tip amount and touch or press [ENTER].  |
| Total Correct?<br>NO                                 |  | ADJUST<br>\$\$<br>YES  | Touch Yes or press [ENTER] if amount is correct. Touch No or and change amount if not correct.   |
| RESPONSE<br>TRANSACTION ACCEPTED                     |  | Approval code displays. Receipt prints. Terminal returns to idle prompt. |  |

**ADD/REMOVE CASHIER (LOG ON/LOG OFF)**

|                                  |                    |  |  |
|----------------------------------|--------------------|--|--|
| IDLE PROMPT<br>Press here for... |                    | Press [MENU] and then [CASHIER].   |  |
| ADD/REMOVE REPORTS               | CASHIER VIEW CLEAR | X  | Press [ADD/REMOVE].  |
| Enter Cashier #<br><--           | SIGN/OFF CLEAR     | X  | Key in cashier number and touch or press [ENTER].                              |
| Sign On?                         | NO YES             | X  | Choose [NO] to abort task; choose [YES] to sign cashier on or off.             |
| RESPONSE<br>TRANSACTION ACCEPTED |                    | Approval code displays. Receipt prints. Terminal returns to idle prompt. |  |
| Enter Cashier #<br><--           | SIGN/OFF CLEAR     | X  | If additional cashiers are required, key in cashier number. If not, touch [X]. |

**CASHIER REPORT**

|                                       |                          |   |  |
|---------------------------------------|--------------------------|---|--|
| IDLE PROMPT<br>Press here for...      |                          | Press [MENU] and then [REPORT].                 |  |
| AUDIT REPORT                          | REPORTS SUMMARY CASHIER  | X   | Press [CASHIER].   |
| DETAIL UNADJUSTED                     | REPORTS SUMMARY CASHIERS | X   | Select appropriate option. (CASHIER is a list from the Cashier table.) |
| Enter Cashier #<br><--                | REPORTS CLEAR            | X   | Key in desired cashier number, or press [ENTER] for all.               |
| REPORTS Scanning Batch Please Wait... |                          | Report prints. Terminal returns to idle prompt. |  |

**DETAIL REPORT**

|                                   |                         |                                 |  |
|-----------------------------------|-------------------------|---------------------------------|--|
| IDLE PROMPT<br>Press here for...  |                         | Press [MENU] and then [REPORT]. |  |
| AUDIT REPORT                      | REPORTS SUMMARY CASHIER | X                               | Press [AUDIT].   |
| 00 - ALL<br>02 - PNS<br>03 - AMEX | OPTIONS                 | X                               | Choose the appropriate option.<br>ALL = all hosts.<br>PNS = Paymentech Network Services.<br>AMEX = American Express. |
| PLEASE WAIT Printing...           |                         | No action while processing.     |  |

**SUMMARY REPORT**

|                                       |                         |   |                  |
|---------------------------------------|-------------------------|---|------------------|
| IDLE PROMPT<br>Press here for...      |                         | Press [MENU] and then [REPORT].                 |                  |
| AUDIT REPORT                          | REPORTS SUMMARY CASHIER | X   | Press [SUMMARY]. |
| REPORTS Scanning Batch Please Wait... |                         | Report prints. Terminal returns to idle prompt. |                  |

Shaded sections are optional features.

**DEBIT**

|  |                      |  |  |
|--|----------------------|--|--|
| IDLE PROMPT<br>Press here for...         |                      | Press [MENU], [NEW TRANS], and then [SALE].                              |  |
| CREDIT EBT                               | SALE DEBIT PRIOR EBT | X  | Press [DEBIT]  |
| Swipe customer card                      |                      | X  | Swipe card or key in card number.  |
| DEBIT<br>Enter Cashier Number<br><--     | SAL+CSH CLEAR        | X  | Key in cashier number and touch or press [ENTER].  |
| DEBIT<br>Sale Amount<br><--              | SAL+CSH CLEAR        | X  | Key in sale amount and touch or press [ENTER].   |
| DEBIT<br>Cash Amount<br><--              | SAL+CSH CLEAR        | X  | Key in cash-back amount and touch or press [ENTER].  |
| DEBIT<br>Total Correct?<br>NO YES<br><-- | SAL+CSH CLEAR        | X  | Touch Yes or press [ENTER] if amount is correct. Touch No or and change amount if not correct. |
| Total Amount \$\$\$.                     |                      | Customer keys in PIN on PIN pad and presses [ENTER].                     |  |
| Enter your PIN and press ENTER<br><--    |                      | CLEAR  |  |
| RESPONSE APPROVAL XXXXXX                 |                      | Approval code displays. Receipt prints. Terminal returns to idle prompt. |  |

**DEBIT REFUND**

|  |              |  |   |
|--|--------------|--|---|
| IDLE PROMPT<br>Press here for...         |              | Press [MENU], [NEW TRANS], and then [REFUND].                            |   |
| CREDIT EBT                               | REFUND DEBIT | X  | Press [DEBIT]                                     |
| Swipe Customer Card                      |              | X  | Key in card number and touch or press [ENTER].    |
| CARD TYPE<br>Enter Cashier Number<br><-- | REFUND CLEAR | X  | Key in cashier number and touch or press [ENTER]. |
| CARD TYPE<br>Amount<br><--               | REFUND CLEAR | X  | Key in amount and touch or press [ENTER].         |
| Total Amount \$\$\$.                     |              | Customer keys in PIN on PIN pad and presses [ENTER].                     |   |
| Enter your PIN and press ENTER<br><--    |              | CLEAR  |   |
| RESPONSE TRANSACTION ACCEPTED            |              | Approval code displays. Receipt prints. Terminal returns to idle prompt. |   |

**EBT**

|                                |            |   |   |
|--------------------------------|------------|---|---|
| IDLE PROMPT                    |            | Press [MENU], [NEW TRANS], and then [SALE]. |   |
| Press here for...              |            |   |   |
| SALE CREDIT                    | DEBIT CARD | X   | Press [EBT]   |
| EBT                            | PRI OR EBT |   |   |
| EBT                            | EBT        | X   | Swipe card.   |
| Swipe customer card            |            |   |   |
| EBT                            | EBT        | X   | Select [1] for a food stamp transaction or [2] for a cash benefit transaction.              |
| Select Item                    |            |   |   |
| 1 - Food Stamp                 |            |   |   |
| 2 - Cash Benefit               |            |   |   |
| EBT                            | EBT        | X   | Key in cashier number and touch or press [ENTER].   |
| Enter Cashier Number           |            |   |   |
| <--                            | Clear      | Enter                                       |   |
| EBT                            | EBT        | X   | Key in sale amount and touch or press [ENTER].  |
| Sale Amount                    |            |   |   |
| <--                            | Clear      | Enter                                       |   |
| EBT                            | EBT        | X   | Key in cash-back amount and touch or press [ENTER].   |
| Cash Amount                    |            |   |   |
| <--                            | Clear      | Enter                                       |   |
| EBT                            | EBT        | X   | Touch Yes or press [ENTER] if amount is correct. Touch No and change amount if not correct. |
| Total Correct? \$\$            |            |   |   |
| <--                            | NO YES     | Enter                                       |   |
| Total Amount \$\$\$.           |            |   | Customer keys in PIN on PIN pad and presses [ENTER].  |
| Enter your PIN and press ENTER |            |   |   |
| <--                            | Clear      | Enter                                       |   |
| RESPONSE APPROVAL XXXXXX       |            |   | Approval code displays. Receipt prints. Terminal returns to idle prompt.                    |

**EBT FORCED SALE**

|                          |            |   |  |
|--------------------------|------------|---|--|
| IDLE PROMPT              |            | Press [MENU], [NEW TRANS], and then [SALE]. |  |
| Press here for...        |            |   |  |
| CREDIT CARD              | DEBIT CARD | X   | Select appropriate tender.   |
| EBT REFUND               | PRI OR EBT |   |  |
| EBT                      | EBT        | X   | Swipe card.  |
| Swipe customer card      |            |   |  |
| <--                      | Clear      | Enter                                       |  |
| CARD TYPE                | EBT        | X   | Key in cashier number and touch or press [ENTER].                        |
| Enter Cashier Number     |            |   |  |
| <--                      | Clear      | Enter                                       |  |
| CARD TYPE                | EBT        | X   | Key in amount and touch or press [ENTER].                                |
| Amount                   |            |   |  |
| <--                      | Clear      | Enter                                       |  |
| CARD TYPE                | EBT        | X   | Key in approval code and press [ENTER].                                  |
| Enter Approval Code      |            |   |  |
| <--                      | Clear      | Enter                                       |  |
| CARD TYPE                | EBT        | X   | Key in voucher number and press [ENTER].                                 |
| Enter Voucher Number     |            |   |  |
| <--                      | Clear      | Enter                                       |  |
| RESPONSE APPROVAL XXXXXX |            |   | Approval code displays. Receipt prints. Terminal returns to idle prompt. |

**EBT REFUND**

|                          |        |   |  |
|--------------------------|--------|---|--|
| IDLE PROMPT              |        | Press [MENU], [NEW TRANS], and then [REFUND]. |  |
| Press here for...        |        |   |  |
| CREDIT                   | REFUND | X   | Press [EBT]  |
| EBT                      | DEBIT  |   |  |
| EBT                      | REFUND | X   | Key in card number and touch or press [ENTER].                           |
| Swipe Customer Card      |        |   |  |
| <--                      | Clear  | Enter   |  |
| CARD TYPE                | REFUND | X   | Key in cashier number and touch or press [ENTER].                        |
| Enter Cashier Number     |        |   |  |
| <--                      | Clear  | Enter   |  |
| CARD TYPE                | REFUND | X   | Key in amount and touch or press [ENTER].                                |
| Amount                   |        |   |  |
| <--                      | Clear  | Enter   |  |
| RESPONSE APPROVAL XXXXXX |        |   | Approval code displays. Receipt prints. Terminal returns to idle prompt. |

**REPRINT LAST INVOICE**

IDLE PROMPT Press [MENU], [REPORTS], and then [REPRINT].  
 Press here for . . .

---

REPRINT X Touch [REPRINT LAST].  
 BY INVOICE  
 REPRINT LAST

---

REPRINT X Key in invoice number and touch or press enter.  
 Enter Invoice #  
 <-- Clear Enter

---

RESPONSE Receipt prints. Terminal returns to idle prompt.  
 TRANSACTION ACCEPTED

**REPRINT BY INVOICE NUMBER**

IDLE PROMPT Press [MENU], [REPORTS], and then [REPRINT].  
 Press here for . . .

---

REPRINT X Touch [BY INVOICE].  
 BY INVOICE  
 REPRINT LAST

---

REPRINT X Key in the Station ID of the terminal that originally  
 ran the transaction that is to be reprinted and press [ENTER].  
 Enter Station ID  
 XX (displays current station ID)  
 (The Station ID can be located on the original receipt.)

---

REPRINT X Key in invoice number and touch or press enter.  
 Enter Invoice #  
 <-- Clear Enter

---

REPRINT COMPLETE Receipt prints. Terminal returns to idle prompt.

**AVS RESPONSE CODES**

| VISA | DESCRIPTION  |
|------|--|
| Y    | Yes - Exact match on address and ZIP Code.                       |
| A    | Address matches, ZIP Code does not.                              |
| Z    | ZIP Code matches, address does not.                              |
| N    | Neither address nor ZIP Code match.                              |
| U    | Address information unavailable, or issuer does not support AVS. |
| R    | Retry - Issuer's system unavailable or timed out.                |
| E    | Error - Transaction ineligible for AVS or edit error found.      |
| S    | AVS not supported by issuer.                                     |

  

| MASTERCARD | DESCRIPTION  |
|------------|--|
| X          | Exact - Match on address and 9-digit ZIP Code.                   |
| Y          | Yes - Exact match on address and ZIP Code.                       |
| A          | Address matches, ZIP Code does not.                              |
| W          | Whole - 9-digit ZIP Code matches, address does not.              |
| Z          | ZIP Code matches, address does not.                              |
| N          | Neither address nor ZIP Code match.                              |
| U          | Address information unavailable, or issuer does not support AVS. |
| R          | Retry - Issuer's system unavailable or timed out.                |
| S          | AVS not supported by issuer.                                     |

**AVS CODES CONTINUED**

| DISCOVER | DESCRIPTION  |
|----------|--|
| Y        | Yes - Exact match on address and ZIP Code.                       |
| A        | Address matches, ZIP Code does not.                              |
| W        | Whole - 9-digit ZIP Code matches, address does not.              |
| Z        | ZIP Code matches, address does not.                              |
| N        | Neither address nor ZIP Code match.                              |
| U        | Address information unavailable, or issuer does not support AVS. |

  

| AMERICAN EXPRESS | DESCRIPTION  |
|------------------|--|
| Y                | Yes - Exact match on address and ZIP Code.                       |
| A                | Address matches, ZIP Code does not.                              |
| Z                | ZIP Code matches, address does not.                              |
| N                | Neither address nor ZIP Code match.                              |
| U                | Address information unavailable, or issuer does not support AVS. |
| R                | Retry - Issuer's system unavailable or timed out.                |
| S                | AVS not supported by issuer.                                     |

**CVV2 CODES**

| VISA CODES | CVV2 CODE DESCRIPTION  |
|------------|--|
| M          | CVV2 code matches.   |
| N          | CVV2 code does not match.  |
| P          | CVV2 code was not processed.   |
| S          | CVV2 code was on the card, but the merchant indicated that it was not. |
| U          | The issuer is not certified for CVV2.                                  |

Paymentech™

POS-0405 Hypercom Retail LAN 04/01